



RazorSafe 7-Series Hardware Getting Started Guide

Release: AOS 5.0
September 2010
Part Number: 010-00822c

This manual supports Archiving Operating System (AOS) release 5.0 and later releases, and RazorSafe 7-Series appliances, until replaced by a newer edition.

The Mirapoint Software and Mirapoint documentation are Copyright © 1998-2010 Mirapoint Software, Inc. All Rights Reserved. You may not print, copy, reproduce, modify, distribute or display this work in hard copy, electronic, or any other form, in whole or in part, by any electronic, mechanical, or other means, without the prior written consent of Mirapoint Software, Inc., except that you are permitted to make one copy for archival purposes only in connection with the lawful use and operation of this software.

Mirapoint, RazorGate, and the Mirapoint logo are registered trademarks of Mirapoint Software, Inc. Mirapoint Message Server, Mirapoint Directory Server, Mirapoint Operations Console, RazorSafe, DirectPath, WebMail Direct, WebCal Direct, and GroupCal Direct are trademarks of Mirapoint Software, Inc.

Mirapoint integrates third party software programs within the Mirapoint Software, which are subject to their own license terms. If the user does not agree to abide by the applicable license terms for the integrated third party software programs as defined by the Mirapoint Software License Agreement, then you may not install or operate the Mirapoint Software. These software license agreements, including the Mirapoint Software License Agreement, Red Hat End User License Agreement, and Open LDAP Public License, can be viewed at <http://www.mirapoint.com/licenses/thirdparty/eula.php>.

Portions of this product are Copyright © 1982, 1986, 1989, 1991, 1993 the Regents of the University of California. All Rights Reserved.

Portions of this product are Copyright © Dell Inc. Used with permission.

Portions of this product are Copyright © 2008 Red Hat, Inc. All Rights Reserved. The “Red Hat” trademark and the “Shadowman” logo are registered trademarks of Red Hat, Inc. in the U.S. and other countries.

Portions of this product are Copyright © 1997, 1998 FreeBSD, Inc. All Rights Reserved.

Portions of this product are Copyright © 1996-1998 Carnegie Mellon University. All Rights Reserved.

Portions of this product are Copyright © 1997-1998 the Apache Group. All Rights Reserved.

Portions of this product are Copyright © 1987-2006 Larry Wall. All Rights Reserved. See <http://www.perl.org>.

Portions of this product are Copyright © 1990, 1993-1997 Sleepycat Software. All Rights Reserved.

This software is derived in part from the SSLava™ Toolkit, which is Copyright © 1996-1998 by Phaos Technology Corporation. All Rights Reserved.

Portions of this product are Copyright © 1998, 1999, 2000 Bruce Verderaime. All Rights Reserved.

Portions of this product are Copyright © 1999-2003 The OpenLDAP Foundation, Redwood City, California, USA. All Rights Reserved. Permission to copy and distribute verbatim copies of this document is granted.

OpenLDAP is a registered trademark of the OpenLDAP Foundation.

Macintosh is a trademark of Apple Computer, Inc.

Windows, Outlook, Exchange, and Active Directory are trademarks of Microsoft Corporation.


Java and Solaris are trademarks of Sun Microsystems, Inc.

Linux is a registered trademark of Linus Torvalds.

All other trademarks are the property of their respective owners.

OTHER THAN ANY EXPRESS LIMITED WARRANTIES THAT MIRAPOINT PROVIDES TO YOU IN WRITING, MIRAPOINT AND MIRAPOINT'S LICENSORS PROVIDE THE SOFTWARE TO YOU “AS IS” AND EXPRESSLY DISCLAIM ALL WARRANTIES AND/OR CONDITIONS, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. IN NO EVENT SHALL MIRAPOINT'S LICENSORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY OR CONSEQUENTIAL DAMAGES, HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY (INCLUDING NEGLIGENCE OR OTHER TORT), ARISING IN ANY WAY OUT OF YOUR USE OF THE SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF DAMAGES. MIRAPOINT'S LIABILITY SHALL BE AS LIMITED IN THE LICENSE AGREEMENT.

Contents



1

Mirapoint RazorSafe 170 (RS170) Installation	5
Obtaining Technical Assistance.....	5
Overview	5
Unpacking the Appliance	6
Installing the Rails and Appliance in a Rack	6
Connecting Keyboard, and Monitor	6
Connecting the Power Cable.....	7
Securing the Power Cord.....	7
Connecting Ethernet Cables	7
Powering the Appliance	8
Installing the Bezel (Optional).....	8
Completing the Operating System Setup	8

2

Mirapoint RazorSafe 700 (RS700) Installation	9
Obtaining Technical Assistance.....	9
Overview	9
Unpacking the Appliance	10
Installing the Rails and Appliance in a Rack	10
Connecting Keyboard, and Monitor	10
Connecting the Power Cables.....	11
Securing the Power Cord.....	11
Connecting Ethernet Cables	12
Powering the Appliance	12
Installing the Bezel (Optional).....	12
Completing the Operating System Setup	13



3

Additional Information 15

 Other Information You Might Need 15

 Technical Specifications 16

 RS170 Technical Specifications 16

 RS700 Technical Specifications 19

 S7000-RS Technical Specifications 22

Mirapoint RazorSafe 170 (RS170) Installation

The following provides information and procedures for getting started with a Mirapoint RazorSafe 170 (RS170).



Before performing the following procedures, review the safety instructions provided with the appliance.

Obtaining Technical Assistance

If you need help understanding a procedure in this guide or if the appliance performs unexpectedly, see [Additional Information](#) on page 15 and the *Mirapoint RazorSafe 170 (RS170) Hardware Guide*.

Overview

Installing and configuring your appliance involves the following tasks:

- ◆ [Unpacking the Appliance](#) on page 6
- ◆ [Installing the Rails and Appliance in a Rack](#) on page 6
- ◆ [Connecting Keyboard, and Monitor](#) on page 6
- ◆ [Connecting the Power Cable](#) on page 7
- ◆ [Securing the Power Cord](#) on page 7
- ◆ [Powering the Appliance](#) on page 8
- ◆ [Installing the Bezel \(Optional\)](#) on page 8
- ◆ [Completing the Operating System Setup](#) on page 8

